



CT-535

Wireless ADSL Router

User's Manual

Version A1.1, May 22, 2003



261035-009

Preface

It is designed to provide information to network administrators. It covers the installation, operation and applications of the Wireless ADSL Router



Warning

- Before servicing or disassembling this equipment, always disconnect all power and telephone lines from the wall outlet.
- Use an appropriate power supply and a UL Listed telephone line cord. Specification of the power supply is stated in Appendix A - Specifications.

TABLE OF CONTENTS

CHAPTER 1	INTRODUCTION	1
1.1	Overview	1
1.2	Features	2
1.3	Application.....	3
1.4	Front Panel LED Indicators	4
CHAPTER 2	INSTALLATION	5
2.1	Preparing for Hardware Installation.....	5
2.2	Hardware Installation.....	6
CHAPTER 3	LOGIN VIA THE WEB BROWSER	9
3.1	IP Address.....	9
3.2	Login Procedure.....	10
CHAPTER 4	WEB BASIC CONFIGURATION.....	11
4.1	Version Information.....	11
4.2	Change the Password	11
4.3	ADSL Link Status.....	12
4.4	WAN Setup.....	13
4.4.1	RFC 1483 Bridged	13
4.4.2	RFC 1483 Routed	14
4.4.3	PPPoE	15
4.4.4	PPPoA	17
4.4.5	MER.....	18
4.5	LAN IP Address.....	19
4.6	WLAN Configuration	20
4.6.1	WLAN Basic Parameters.....	21
4.6.2	WLAN Advanced Functions.....	22
4.6.3	WLAN WEP Parameters:	24
4.6.4	Mac Filter.....	25
4.7	Routing.....	26
4.7.1	Enable RIP	27
4.7.2	Static route configuration.....	28
4.8	Save.....	30
4.9	Reboot	31
4.10	Retrieve default settings.....	32

CHAPTER 5	WEB ADVANCED CONFIGURATION	33
5.1	ADSL Mode.....	33
5.2	VLAN	33
5.3	DHCP	34
5.3.1	Enable DHCP.....	34
5.3.2	Disable DHCP.....	34
5.3.3	Add a DHCP Entry	35
5.3.4	Disable DHCP.....	35
5.4	DHCP Relay.....	36
5.4.1	Enable the DHCP Relay.....	36
5.4.2	Disable the BOOTP/DHCP Relay	37
5.5	SNMP.....	38
5.5.1	Modifying SNMP Parameters.....	39
5.5.2	Modifying Traps	40
5.5.3	Modifying Communities.....	41
5.6	Firewall	42
5.6.1	Enable/Disable the Firewall.....	42
5.6.2	View Firewall Actions	43
5.6.3	IP Filtering	43
5.7	NAT	45
5.7.1	Static NAT Mapping.....	45
5.7.2	Static Port Mapping	46
5.8	Configure	47
5.8.1	Configure Interface	48
5.8.2	DNS & Default Gateway	49
5.8.3	NAT	50
5.9	VCC	51
5.9.1	List IPoA.....	51
5.9.2	Delete Encapsulation	52
5.9.3	Add a VCC.....	53
5.9.4	Delete a VCC	55
5.9.5	Show VCC quality	55
5.9.6	PPPoE	55
5.10	PPPoA	56
5.11	IGMP.....	56
5.11.1	Add an IGMP entry.....	57
5.11.2	Delete an IGMP entry	57
5.12	Bridging	58

5.12.1	Bridge.....	58
5.12.2	Spanning tree	59
5.12.3	View STP Parameters	60
5.12.4	To configure STP parameters	61
5.12.5	Enable/Disable STP	61
5.13	Filtering.....	62
5.13.1	List of filter entries.....	62
5.13.2	Add a filter entry	63
5.13.3	Delete a filter entry	63
5.13.4	Modify a filter entry	63
5.13.5	Flush filter entries	63
CHAPTER 6	WEB PERFORMANCE MONITORING.....	64
6.1	ADSL Link Status.....	64
6.2	System Statistics	65
6.2.1	Interface Statistics	65
6.2.2	TCP-IP	66
6.2.3	DHCP-Lease	66
6.3	ATM statistics.....	67
6.3.1	AAL5	67
6.3.2	Encapsulation.....	67
CHAPTER 7	WEB DIAGNOSTICS.....	68
7.1	OAM Loopback	68
7.2	Ping	69
CHAPTER 8	FIRMWARE UPGRADE.....	70
CHAPTER 9	ACCESS BY TELNET	72
9.1	Setting a Common IP Address.....	72
9.2	Telnet Access	73
CHAPTER 10	CONSOLE MANAGEMENT	74
10.1	Hardware connection	74
10.2	Access by Console	74
10.3	Console WLAN Guide.....	76
10.3.1	WLAN Basic Parameters.....	77
10.3.2	WLAN Advanced Functions.....	78
10.3.3	WLAN WEP Parameters:	79
APPENDIX A: SPECIFICATIONS	80
APPENDIX B - PIN ASSIGNMENTS	82

Chapter 1 Introduction

1.1 Overview

The wireless ADSL router combines cutting-edge wireless technology with routing/bridge functions. It enables multiple users to share a high speed ADSL connection, without connecting any wires. To ensure the security of your valuable data the router employs state-of-the-art security features such as WEP data encryption, L2TP, and IpSec pass through. To provide maximum immunity from broadband interference the router incorporates the latest wireless modulation technology (DSSS). The router is designed for residential and business users who need wireless access through an ADSL router.

In addition to wireless connectivity, the wireless ADSL router has four 10/100 Base-T Ethernet ports for LAN connection. It can access the Internet, Corporate LAN, or Video on Demand over one ordinary telephone line, and establish up to 8 concurrent virtual-connections to multiple destinations.

1.2 Features

The Wireless ADSL Router has the following features:

- Wireless built-in ADSL router
- IEEE 802.11b compliance
- 11Mbps/5.5Mbps/2Mbps/1Mbps data rates with auto-fallback support
- WEP data encryption
- Four 10/100 Base-T Ethernet ports for LAN connection
- Bridge/Router
- AAL5 for ATM over ADSL
- UBR/CBR/VBR ATM services
- VC-based and LLC multiplexing
- Up to 8 VCs
- Embedded SNMP agent and RFC MIB II
- Web-based management
- OAM F4 and F5
- Static route/RIP/RIP v2 routing
- Dynamic IP assignment and Network Address Translation

1.3 Application

The following diagram shows a typical application of the router, which can be used for G.lite and G.DMT applications.




Figure 1-1 Application

1.4 Front Panel LED Indicators

The front panel LEDs are shown in the picture below, followed by an explanation in the table below.



LED	Color	Mode	Function
Power	Green	On	The router is powered up
		Off	The router is powered down.
LAN 1x ~ 4x	Green	On	Ethernet connection is established.
		Blink	Data transmitting or receiving
		Off	Ethernet connection is not established.
WLAN	Green	Blink	Data transmitting or receiving over WLAN
		Off	The wireless is not installed.
		On	The wireless module is ready and idle.
ADSL	Green	On	The ADSL connection is established.
		Off	ADSL connection is not established.
ALARM	Red	On	The ADSL link is terminated.
		Off	Normal operating status

Chapter 2 Installation

2.1 Preparing for Hardware Installation


The following equipment may be necessary to install the router:

- ❑ **AC power adapter**
A suitable power adapter is shipped with the router. It is used to provide the necessary power for the router's operation.
- ❑ **LAN connection cable**
To connect to a hub or PC, use an RJ45 cable.
- ❑ **RJ11 cable**
An RJ11 cable is needed to connect to the LINE port.
- ❑ **Optional micro filter and POTS splitter**
If you wish to connect both the router and a telephone, you will need the optional micro filter or POTS splitter.


2.2 Hardware Installation

Follow the instructions below to complete the hardware connections.


- Step 1** Connect the **Line** port to a telephone-line using the supplied RJ-11 cable; or if you wish to connect both the router and a telephone, connect the ADSL port to a micro filter or POTS splitter with a RJ11 connection cable.




- Step 2** To connect to a hub or PC, use a RJ45 cable. You can connect the router to four LAN devices. The ports are auto-sensing MDI/X and either straight-through cable or crossover cable can be used.



Step 3 (Optional) In order to manage your device through the console port you will need to use a straight-through cable with an **RJ-45 connector** to attach to the modem, and a **female RS-232 connector** to connect to the serial port on a PC. The PC must be equipped with a VT-100 emulation program, such as HyperTerminal 5 or Telix.




Step 4 Connect the **Power** jack to the shipped power cord.



Step 5 Attach the power adapter to the wall outlet or other AC source.

Step 6 After all connections have been made, turn the power-switch to the on position. After power on, the router performs a self-test. Wait for a few seconds until the test is finished, then the router will be ready to operate.



Caution 1: If the router fails to power up, or it malfunctions, first verify that the power supply is connected correctly. Then power it on again. If the problem persists, contact our technical support engineers.

Caution 2: Before servicing or disassembling this equipment always disconnect all power cords and telephone lines from the wall outlet.


Chapter 3 Login via the Web Browser

This section describes how to manage the router via a Web browser from the remote end. You can use a web browser such as Microsoft Internet Explorer, or Netscape Navigator. It is best to set your display resolution to 1024 x 768. To change the resolution you can go to the Microsoft Windows control panel and click on the **Display** icon, and change the display settings. You will find the display settings there.

3.1 IP Address

To log on to the device using a web browser, your workstation and the device should both be on the same network segment.

STEP 1: Enter the TCP/IP screen and change the IP address to the domain of 192.168.1.x/24. You should choose an IP address from 192.168.1.132-192.168.1.254 to avoid conflict with IP addresses reserved for the DHCP pool (192.168.1.3 to 192.168.1.131).



STEP 2: Click OK to submit the settings.

STEP 3: Start your Internet browser with the default IP address 192.168.1.1.

3.2 Login Procedure

To log on to the system from the Web browser, follow the steps below:

STEP 1: Start your Internet browser.

STEP 2: Type the IP address for the router in the Web address field. For example, if the IP address is 192.168.1.1, type **http://192.168.1.1**

STEP 3: You will be prompted to enter your user name and password. Type the password, or if the password was not changed, type the default passwords. The default USER name is **root**, and the default password is **12345** (some versions require a login of 1234).

STEP 4: After successfully logging in, you will reach the main menu.




The image shows a screenshot of a web-based configuration interface. At the top left, there is a tab labeled "Password". The main heading is "Password Configuration". Below the heading, there are three input fields: "Old Password:", "New Password:", and "Confirm Password:". At the bottom of the dialog, there are two buttons: "Apply" and "Cancel".

Chapter 4 Web Basic Configuration

From the **Basic** menu bar, you can verify the software version, change passwords, configure the WAN/LAN interfaces, set-up routing, save settings, reboot the device, and retrieve the factory default settings.

4.1 Version Information

To verify the software version of your router, from the **Basic** Menu bar, click on **Version Information**. The information will display as in the screenshot below.



The screenshot shows a light blue window titled "SW Information". It contains three text input fields with labels to their left: "Product Name : ADSL_Router", "Release Version : V1.3.2(R)", and "Build Time : Mar 31 2003 10:53:40".

4.2 Change the Password



The screenshot shows a light blue window titled "Password Configuration" with a "Password" tab at the top. It contains three text input fields with labels to their left: "Old Password:", "New Password:", and "Confirm Password:". At the bottom, there are two buttons: "Apply" and "Cancel".

To modify the password, click **Change Password** from the menu bar. Type the old password and type the new password twice. Click **Apply** to submit the settings.

If you change the password, make sure you keep a record of it in a safe place, as you will require it next time you log-on.

4.3 ADSL Link Status

To view the ADSL link status, click **Link Status** from the tool bar. The page includes the following information:

LinkStatus	
ADSL Link Status	
Adsl Line Status	UNTRAINED
Adsl Mode	MULTI
Up Stream	0 kb (Interleave)
Down Stream	0 kb (Interleave)
Attenuation	Near End: 0.0
	Far End: 0.0
SNR Margin	Near End: 0
	Far End: 0
HEC Count	0
Firmware	0x42e2ea53
15 min ES Counter	0
CRC Errors	0
1 day ES Counter	0

ADSL Line Status	Shows the current status of the ADSL line
ADSL Mode	Shows the ADSL standard that is currently configured. The standards are: ANSI, G.DMT, G.LITE, MULTI.
Upstream	Upstream data rate negotiated by DSL link (Kbit/s)
Downstream	Downstream data rate negotiated by DSL link (Kbit/s)
Attenuation	Current attenuation (dB) of both near end and far end.
SNR Margin	Current SNR margin (dB)
HEC	Number of ATM cells received with errors, since start of link.
Firmware	The version number of the firmware
15 min ES counter	Number of errored seconds for the current 15 minute period
CRC errors	Number of errors per second since training
1 day ES counter	Number of errored seconds for the current day

4.4 WAN Setup

Click WAN Setup from the tool bar and configure the WAN interface for these services: RFC1483 Bridged, RFC1483 Routed, PPPoE, PPPoA, and MER. The following are the common settings to set up these services.

- ◆ VPI and VCI
- ◆ LLC Encapsulation: With LLC encapsulation, a link control header is added to the Ethernet packet that identifies the protocol type (Ethernet). This allows multiple protocols to be transmitted over the ATM Virtual Circuit.
- ◆ VC Multiplexing: With VC Multiplexing, no link control header is needed as the ATM Virtual Circuit is assumed to be carrying a single protocol.
- ◆ Enable NAPT: NAPT or Network Address Port Translation, enables the translation of private and public addresses. This feature is available for RFC 1483 Routed, PPPoE, PPPoA, and MER. It is enabled for PPPoE.

4.4.1 RFC 1483 Bridged

When using RFC 1483 style bridging, Ethernet frames are “bridged” over ATM Virtual Circuits. The Ethernet frames are encapsulated using either LLC Encapsulation or VC Multiplexing. With LLC encapsulation, a link control header is added to the Ethernet packet that identifies the protocol type (Ethernet). This allows multiple protocols to be transmitted over the ATM Virtual Circuit. With VC Multiplexing, no link control header is needed as the ATM Virtual Circuit is assumed to be carrying a single protocol. Since the Ethernet packets are bridged, the router’s only responsibility is to pass the Ethernet packets to and from the Internet Service Provider and the local network. The IP addresses of the local network are assigned by the ISP either statically or dynamically.

ADD AN ENTRY

To set up the RFC 1483 Bridged, configure the common fields on the top of the page and click the Add button to add the entry.



The screenshot shows the WAN Setup configuration interface. At the top, the title "WAN Setup" is displayed. Below the title, there are several configuration options: "VPI : 0" (with a text input field containing "0"), "VCI : " (with an empty text input field), a radio button selected for "LLC/SNAP", a radio button for "Vc Multiplexing", and a checkbox for "Enable NAPT". At the bottom left, the "RFC1483 Bridged" option is selected with a radio button.

MODIFY AN ENTRY

To modify an entry, complete the following steps:

STEP 1: Select the entry from the **Current ATM PVC List**, at the bottom of the WAN Setup page. The current values of the selected entry will display in the upper section of the page.

STEP 2: Change the parameters.

STEP 3: Click **Modify**.

DELETE AN ENTRY

To delete an entry, Select it from the **Current ATM PVC List**, at the bottom of the WAN Setup page, and click the **Delete** button.

4.4.2 RFC 1483 Routed

ADD AN ENTRY

To set up the RFC 1483 Routed, configure the common settings on the top of the page, click RFC 1483 Routed and configure the specific settings (WAN IP address and WAN subnet mask). Click the Add button to add the entry.

The screenshot shows the WAN Setup configuration interface. At the top, the title "WAN Setup" is displayed. Below the title, there are several configuration options: "VPI : 0" with a text input field, "VCI : " with a text input field, and three radio buttons: "LLC/SNAP" (selected), "Vc Multiplexing", and "Enable NAP" (checkbox). Below these options, there are two radio buttons for selecting the configuration mode: "RFC1483 Bridged" and "RFC1483 Routed" (selected). Under the "RFC1483 Routed" option, there are two text input fields: "WAN IP address:" and "WAN subnet mask:".

MODIFY AN ENTRY

To modify an entry, complete the following steps:

STEP 1: Select the entry from the **Current ATM PVC List**, at the bottom of the WAN Setup page. The current values of the selected entry will display in the upper section of the page.

STEP 2: Change the parameters.

STEP 3: Click **Modify**.

DELETE AN ENTRY

To delete an entry, Select it from the **Current ATM PVC List**, at the bottom of the WAN Setup page, and click the **Delete** button.

4.4.3 PPPoE

PPPoE provides service providers similar billing and access control as present in dial-up services. In addition, with direct support to Ethernet it provides a low cost solution to supporting multiple hosts at the customer premises. PPPoE provides session authentication using either Password Authentication Protocol (PAP) or Challenge Handshake Authentication Protocol (CHAP). Session accounting is possible and conservation of bandwidth can be done by closing down unused sessions. By utilizing PPP, link and network parameters are easily negotiated between the IAD/Router and the ISP.

When using PPPoE, the system is assigned an IP address from the Internet Service Provider as part of establishing the network connection. The system can be configured as a DHCP server for its LAN and NAT can be used to translate private addresses to public addresses. In this way, computers in the LAN do not have to have their own public IP addresses.

The image shows a 'WAN Setup' configuration page. At the top, there are fields for 'VPI : 0' and 'VCI :', followed by radio buttons for 'LLC/SNAP', 'Vc Multiplexing', and 'Enable NAPT'. Below this, there are four main configuration options: 'RFC1483 Bridged', 'RFC1483 Routed', 'PPPoE', and 'PPPoA (NAT Enabled)'. The 'PPPoE' option is selected and highlighted with a red box. It includes fields for 'User name:', 'Password:', 'Mode:' (set to 'auto'), 'Idle Timeout(min):', and 'Authentication:' (set to 'PAP'). There is also an 'Enable DHCP Server:' checkbox. Below the 'PPPoE' section, there are 'Add', 'Modify', and 'Delete' buttons. At the bottom, there are 'Manual Mode:' (set to 'Enable') and 'Manual Mode Trigger:' (set to 'Trigger') fields.

ADD AN ENTRY

To set up PPPoE, click PPPoE, configure the common fields on the top of the page, as well as the following fields. At the bottom of the screen, click the **Add** button to add the entry. In addition, If the PPPoE mode is set to **auto**, clicking the MANUAL MODE **Enable** button will effectively disable auto mode, and require the user to reconnect a terminated PPPoE session by clicking the MANUAL MODE **Trigger** button. Subsequently, to return to Auto-mode, click on the MANUAL MODE **Disable** button, which will appear in place of the MANUAL MODE **Enable** button.

- ◆ **User name/Password:** used for the remote customers to login during dialup.
- ◆ **Mode:** Direct and Auto. If the mode is set to AUTO, the PPPoE negotiation automatically starts when the system identifies any traffic required to be transferred on the link. When DIRECT is selected the PPPoE negotiation is started manually using the "pppoestart" command. The default is DIRECT.
- ◆ **Idle Timeout:** defines the period of idle time (minutes) after which the PPPoE link will be terminated.
- ◆ **Authentication:** defines the authentication code: PAP, and CHAP
- ◆ **Enable DHCP Server:** enables the DHCP server. This field is automatically checked when PPPoE is selected. Deselect the field to disable the DHCP server. The DHCP server dynamically allocates network addresses and delivers configuration parameters to hosts.

MODIFY AN ENTRY

To modify an entry, complete the following steps:

STEP 1: Select the entry from the **Current ATM PVC List**, at the bottom of the WAN Setup page. The current values of the selected entry will display in the upper section of the page.

STEP 2: Change the parameters.

STEP 3: Click **Modify**.

DELETE AN ENTRY

To delete an entry, Select it from the **Current ATM PVC List**, at the bottom of the WAN Setup page, and click the **Delete** button.

4.4.4 PPPoA

ADD AN ENTRY

To set up PPPoA, click PPPoA, configure the common fields and the following fields. Click the Add button to add the entry.

- ◆ **User name** and **Password**: used for remote customers to login upon dialup. PPPoA is manually activated by entering startup commands from the page: Advanced>Configure PPPoA. The **Authentication** field defines the authentication code: PAP or CHAP.
- ◆ **Authentication**: defines the authentication code (PAP, CHAP).

The screenshot shows the 'WAN Setup' configuration page. At the top, there are fields for VPI (set to 0) and VCI, and radio buttons for LLC/SNAP, Vc Multiplexing, and Enable NAPT (checked). Below this are four main configuration sections, each with a radio button:

- RFC1483 Bridged**: No further fields are visible.
- RFC1483 Routed**: Fields for WAN IP address and WAN subnet mask.
- PPPoE (NAT Enabled)**: Fields for User name, Password, Mode (set to 'direct'), Idle Timeout (min), Authentication (set to 'PAP'), and Enable DHCP Server (checkbox).
- PPPoA (NAT Enabled)**: Fields for User name, Password, and Authentication (set to 'PAP'). This section is highlighted with a red box.
- MER**: Fields for IP Address and Subnet mask.

MODIFY AN ENTRY

To modify an entry, complete the following steps:

STEP 1: Select the entry from the **Current ATM PVC List**, at the bottom of the WAN Setup page. The current values of the selected entry will display in the upper section of the page.

STEP 2: Change the parameters.

STEP 3: Click **Modify**.

DELETE AN ENTRY

To delete an entry, Select it from the **Current ATM PVC List**, at the bottom of the WAN Setup page, and click the **Delete** button.

4.4.5 MER

MAC Encapsulation Routing (MER) enables the ATU-R to route IP addresses on the RFC1483 bridged link. NAPT function is supported to allow multiple private IP addresses on the LAN to share a public IP address.

To set up the MER service, configure the common fields, and then enter the IP Address and Subnet Mask under the MER section of the screen. Click the Add button to add the entry.

The screenshot shows the 'WAN Setup' configuration page. At the top, there are fields for VPI (set to 0) and VCI, and radio buttons for LLC/SNAP, Vc Multiplexing, and Enable NAPT (checked). Below this are four main sections: RFC1483 Bridged, RFC1483 Routed, PPPoE (NAT Enabled), and PPPoA (NAT Enabled). The MER section at the bottom is highlighted with a red box and contains fields for IP Address and Subnet mask. At the bottom of the page are three buttons: Add, Modify, and Delete.

To modify an entry, complete the following steps:

STEP 1: Select the entry from the **Current ATM PVC List**, at the bottom of the WAN Setup page. The current values of the selected entry will display in the upper section of the page.


STEP 2: Change the parameters.

STEP 3: Click **Modify**.

To delete an entry, Select it from the **Current ATM PVC List**, at the bottom of the WAN Setup page, and click the **Delete** button.

4.5 LAN IP Address

Click **LAN Setup** from the menu bar to configure the LAN IP address. Type the **IP address** and **subnet mask**. Click **Apply** to submit the settings. When the new IP address is applied, the Web configuration will be interrupted. Use the new IP address to login.



The screenshot shows a web interface for LAN Setup. At the top left, there is a tab labeled "LAN Setup". Below this, the title "LAN Setup" is centered. There are two input fields: "LAN IP Address :" followed by a text box, and "Subnet :" followed by another text box. At the bottom, there are two buttons: "Apply" and "Cancel".

4.6 WLAN Configuration

Parameters that specifically deal with the wireless functions of your router can be accessed from **WLAN Setup** on the Basic menu bar. The menu is subdivided into three menus: WLAN Basic, WLAN Advanced, and WLAN WEP. Each of these menus will be covered below.



The screenshot shows the 'Wireless LAN Basic Setup' configuration page. The left sidebar contains a menu with the following items: 'Change Password', 'Link Status', 'WAN Setup', 'LAN Setup', 'WLAN Setup' (highlighted in red), 'Routing Setup', and 'Save &'. The top navigation bar has tabs for 'Basic', 'Advance', 'WEP', and 'MAC Filter'. The main content area is titled 'Wireless LAN Basic Setup' and contains the following fields:

- IP Address :
- Subnet :
- SSID :
- Channel :

At the bottom of the form are three buttons: 'Apply', 'Restore', and 'Cancel'.

4.6.1 WLAN Basic Parameters

To access the WLAN Basic parameters click on the **WLAN Basic** tab on the **WLAN Settings** screen. The WLAN Basic Parameters menu includes the parameters listed below. After changing any parameters, click on the **Apply** button to update the parameters, or click on the **Restore** button to retain the original settings.

IP Address	Enter the IP address for the WLAN interface
Subnet Mask	Enter a subnet mask for the WLAN interface
SSID	The SSID should match with your client adapters. The SSID (Service Set ID) allows you to uniquely identify your Access Point in the radio environment.
Channel	The channel should match with client adapters. The Direct Sequence Spread Spectrum (DSSS) channel number is an identifier for the frequency on which your WLAN connectivity is enabled in the WLAN network. Although the configurable DSSS channel number range is from 1 up to 14, restrictions apply depending on the country where the Wireless ADSL-Router is used: FCC : channels 1 to 11 ETSI : channels 1 to 13.

The screenshot shows the 'Wireless LAN Basic Setup' configuration page. At the top, there are four tabs: 'Basic', 'Advance', 'WEP', and 'MAC Filter'. The 'Basic' tab is currently selected. Below the tabs, the title 'Wireless LAN Basic Setup' is centered. The configuration fields are as follows:

- IP Address :
- Subnet :
- SSID :
- Channel :

At the bottom of the form, there are three buttons: 'Apply', 'Restore', and 'Cancel'.

4.6.2 WLAN Advanced Functions

To access the WLAN Advanced parameters click on the **WLAN Advance** tab on the **WLAN Settings** screen. The WLAN Advanced Parameters menu includes the parameters listed below. After changing any parameters, click on the **Apply** button to update the parameters, or click on the **Restore** button to retain the original settings.

Beacon Interval	Specify the Beacon Interval value. Enter a value between 1 and 1000. The value represents the time in nano-seconds that Beacon packets are sent by an Access Point to synchronize a wireless network.
RTS Threshold	This value should normally remain at its default setting of 2,432. Should you encounter inconsistent data flow, only minor modifications are recommended. The value must match with remote clients.
Fragmentation	This field is used to specify the fragmentation threshold. Enter a value between 256 and 2346. If you experience a high packet error rate, try to slightly increase your Fragmentation Threshold. The value should normally remain at its default setting of 2,346. This value must match client adapters.
DTIM Interval	Enter a value between 1 and 65535. This number represents the time between sending delivery traffic identification messages (DTIMs) used for power saving and multicast/broadcast delivery. A DTIM is a countdown informing clients of the next window for listening to broadcast and multicast messages. When the AP has buffered broadcast or multicast messages for associated clients, it sends the next DTIM with a DTIM Interval value. AP Clients hear the beacons and awaken to receive the broadcast and multicast messages.
Preamble Type	long, short . Should match client adapters. Short enables faster throughput, but it can only be used when all network elements comply with the IEEE 802.11b standard.
Auth. Type	Open System [no security], Shared Key [select this option if you wish to enable WEP security], if you select both , then both Open System and Shared Key will be simultaneously enabled.
Tx Rates	The transfer rate of the router should be equal to or greater than the clients, the options are: 1-2-5-11 (Mbps).

Wireless LAN Advance Setup

Beacon Interval :

RTS Threshold :

Fragmentation :

DTIM Interval :

Preamble Type :

Auth. Type :

Tx Rate :

Apply

Restore

Cancel

4.6.3 WLAN WEP Parameters:

To access the WLAN WEP parameters click on the **WLAN WEP** tab on the **WLAN Settings** screen. This screen is used to set-up WEP security. WEP security uses an encryption keyword on all transmitted and received data. The parameters are described below. After changing any parameters, click on the **Apply** button to update the parameters, or click on the **Restore** button to retain the original settings.

Key Type	Disabled, 64 bits, 128 bits. This parameter determines the level of security. Disabled means no security, 128 bits provides the highest security. This parameter must match with the remote-clients.
Key Generation	Select Passphrase to enable automatic key generation, or Manual to manually enter each key
Passphrase	Enter a Passphrase if you wish clients to require a Passphrase to connect with the access point.
KeySelect	Select a Key from 0~3. This key will be the active hexadecimal password for access.
Key 0~3	If you are using a manual Passphrase enter a hexadecimal password for each key. This hexadecimal password will be required to be set on any wireless client that you wish to connect with your access point.

4.6.4 Mac Filter

This screen allows access to be restricted/enabled based on a MAC address. Enter the following parameters and then click the **Add** button.

MAC address: Enter the MAC address of the access point.

Auth Type: enter **Open System** to allow unrestricted access to the access point, or **Share Key** to require confirmation with the parameters of the WEP security keys (Click the WEP tab to verify these settings).

MAC Filter Setup

MAC Address : : : : : :

Auth. Type :

Select	MAC Address	Auth. Type
<input type="radio"/>		% AUTHTYPE%

To **delete an entry** select the entry at the bottom of the screen and then click the **Delete** button, located in the middle of the screen.

4.7 Routing

Click **Routing Setup** from the menu bar to configure the routing functions. Routing functions includes RIP and static routing. You can display the RIP information by clicking the **RIP information** button.

Routing Setup

Destination Network ID :

Destination Subnet Mask :

Next Hop IP :

Next Interface :

List of Static Routes

Select	Network ID	Subnet Mask	Next Hop IP	Flag
<input type="radio"/>	10.0.0.0	255.255.255.252	10.0.0.1	C
<input type="radio"/>	172.16.4.0	255.255.255.0	172.16.4.116	C

Rip Information

Rip Status : Version :

4.7.1 Enable RIP

To enable the RIP, complete the following steps:

STEP 1: Click **Routing Setup** from the menu bar

STEP 2: Select **On** in the Rip Status field.

STEP 3: Select a RIP Version (Version 1 or Version 2) from the Version field.

STEP 4: Click **Apply** to submit the settings.

Routing Setup

Routes Configuration

Destination Network ID :

Destination Subnet Mask :

Next Hop IP :

List of Static Routes


Select	Network ID	Subnet Mask	Next Hop IP
<input type="radio"/>	10.0.0.0	255.255.255.252	10.0.0.1
<input type="radio"/>	172.16.4.0	255.255.255.0	172.16.4.72
<input type="radio"/>	192.168.201.0	255.255.255.0	192.168.201.1

Rip Information

Rip Status : Version :

4.7.2 Static route configuration

The Routes Configuration field allows you to add, modify, and delete a static route. Type the Destination Network ID, subnet mask, and next hop IP and click a button below to perform the requested function.



The image shows a 'Routing Setup' configuration form. It contains three text input fields for 'Destination Network ID', 'Destination Subnet Mask', and 'Next Hop IP'. Below these is a radio button selection for 'Next Interface', with 'ATM0' selected in a dropdown menu. At the bottom are three buttons: 'Add', 'Modify', and 'Delete'.

Routing Setup

Destination Network ID :

Destination Subnet Mask :

Next Hop IP :

Next Interface : ATM0 ▾

Add:

To add a static route complete the following steps:

STEP 1: Click **Routing Setup** from the menu bar.

STEP 2: Enter parameters for **Destination Network ID, Subnet Mask, Next Hop IP, and Next Interface** (note you must select between entering a Next Hop IP or Next interface).

STEP 3: Click the **ADD** button.

Modify:

To modify a static route complete the following steps:

STEP 1: Select the entry you wish to modify from the List of Static Routes.

STEP 2: Change the parameters.

STEP 3: Click the **Modify** button.

Delete:


STEP 1: Select the entry you wish to **delete** from the List of Static Routes

STEP 2: Change the parameters.

STEP 3: Click the **Delete** button.


4.8 Save

To save the settings to Flash, click Save & Reboot from the menu bar. In the main pane, click **Save**.




4.9 Reboot

To reboot the router, click **Save & Reboot** from the menu bar. In the main pane, click on **Reboot**.



4.10 Retrieve default settings


To retrieve the default settings, click **Erase & Reboot** from the menu bar. In the main pane, click **Erase**.



Chapter 5 WEB Advanced Configuration

5.1 ADSL Mode

The ADSL modes are: ANSI, G.DMT, G.LITE, MULTI. MULTI mode enables the device to auto-adjust its mode to match the remote CO DLSAM. You can specify an ADSL mode on this page, and click the Apply button to submit the settings.



ADSL Mode

ADSL Standard : MULTI


Apply Cancel

5.2 VLAN

To configure the VLAN function, click **VLAN** from the Advanced menu bar. VLAN is disabled by factory default. To enable it, tick **Enable** and click the **Set** button. Then you can proceed to create the VLAN groups. The ATU-R supports four VLAN groups, VLAN groups 1 to 4. You can choose and join different Ethernet ports to the PVC running in RFC 1483 bridged mode. Packets will be transmitted or received from these ports to the appointed PVC. The packets of the VLAN groups are not routable. Packets that don't belong to the VLAN group are routable.

Parameters and buttons

The PVC field displays the options of the PVCs set up in RFC 1483 Bridged mode (refer to section 5.4, WAN Setup). Click the Set button to apply the settings, or click the Clear button to delete a VLAN group.



VLAN Information

VLAN: Enable Disable Set

VLAN	Ethernet Port	PVC	Action
VLAN1	<input type="checkbox"/> LAN1 <input type="checkbox"/> LAN2 <input type="checkbox"/> LAN3 <input type="checkbox"/> LAN4	003	Set Clear
VLAN2	<input type="checkbox"/> LAN1 <input type="checkbox"/> LAN2 <input type="checkbox"/> LAN3 <input type="checkbox"/> LAN4	003	Set Clear
VLAN3	<input type="checkbox"/> LAN1 <input type="checkbox"/> LAN2 <input type="checkbox"/> LAN3 <input type="checkbox"/> LAN4	003	Set Clear
VLAN4	<input type="checkbox"/> LAN1 <input type="checkbox"/> LAN2 <input type="checkbox"/> LAN3 <input type="checkbox"/> LAN4	003	Set Clear

5.3 DHCP

The Dynamic Host Configuration Protocol (DHCP) provides a centralized approach to allocating IP addresses. It allows IP addresses to be dynamically assigned on an as needed basis, from a pool of addresses. The DHCP function of the device is disabled by factory default.

5.3.1 Enable DHCP

STEP 1: Click the **DHCP** tab.



The screenshot shows the DHCP Server configuration page. At the top, there are two tabs: "DHCP Server" (selected) and "DHCP Relay". Below the tabs is the title "List of DHCP Entries". A table with 10 columns is displayed: "Select", "IfName", "Subnet", "NetMask", "Start Ip", "End Ip", "Gateway", "Broadcast", "DNS", and "Lease Time". The first row contains the following data: a radio button, "eth0", "192.168.1.0", "255.255.255.0", "192.168.1.2", "192.168.1.12", "NA", "NA", "NA", and "0". Below the table are three buttons: "Add", "Delete", and "Start".

Select	IfName	Subnet	NetMask	Start Ip	End Ip	Gateway	Broadcast	DNS	Lease Time
<input type="radio"/>	eth0	192.168.1.0	255.255.255.0	192.168.1.2	192.168.1.12	NA	NA	NA	0

Add **Delete** **Start**

STEP 2: Chose the entry and click the **Start** button

5.3.2 Disable DHCP

STEP 1: Click the **DHCP** tab.

STEP 2: Chose the entry and click the **Stop** button



The screenshot shows the DHCP Server configuration page. At the top, there are two tabs: "DHCP Server" (selected) and "DHCP Relay". Below the tabs is the title "List of DHCP Entries". A table with 10 columns is displayed: "Select", "IfName", "Subnet", "NetMask", "Start Ip", "End Ip", "Gateway", "Broadcast", "DNS", and "Lease Time". The first row contains the following data: a radio button, "eth0", "192.168.1.0", "255.255.255.0", "192.168.1.2", "192.168.1.12", "NA", "NA", "NA", and "0". Below the table are three buttons: "Add", "Delete", and "Stop".

Select	IfName	Subnet	NetMask	Start Ip	End Ip	Gateway	Broadcast	DNS	Lease Time
<input type="radio"/>	eth0	192.168.1.0	255.255.255.0	192.168.1.2	192.168.1.12	NA	NA	NA	0

Add **Delete** **Stop**

5.3.3 Add a DHCP Entry

To add an entry, click the Add button, and fill out the following parameters. Click **Apply** to submit the settings.

The screenshot shows a web-based configuration interface for a DHCP server. It features a dark blue header with two tabs: 'DHCP Server' and 'DHCP Relay'. The main content area is light blue and titled 'DHCP Server Configuration'. The form includes the following fields:

- Interface: A dropdown menu with 'eth0' selected.
- Starting IP Address: An empty text input field.
- End IP Address: An empty text input field.
- Gateway: A text input field containing '172.16.4.72'.
- Netmask: A text input field containing '255.255.255.0'.
- DNS: A text input field containing '172.16.4.72'.
- Lease Time (in Days): A text input field containing '7'.

At the bottom of the form are two buttons: 'Apply' and 'Cancel'.

- ◆ **Interface: eth0 only.** This displays the interface that will provide the DHCP function.
- ◆ **Starting IP Address:** The first IP address of the address pool in the DHCP server. Note the IP address should be in the same subnet as the router's LAN IP address.
- ◆ **End IP Address:** The last IP address of the address pool in the DHCP server. Note the IP address should be in the same subnet as the router's LAN IP address.
- ◆ **Gateway:** The gateway IP address
- ◆ **Netmask:** The subnet mask of the IP network
- ◆ **DNS:** The IP address of the Domain Name Server
- ◆ **Lease Time (in Days):** Upon login, the remote workstation will obtain an IP address. This field defines the period of time that the workstation can use this IP address to access the Internet.

5.3.4 Disable DHCP

STEP 1: Click **DHCP** from the menu bar.

STEP 2: Choose a DHCP entry, and click **Delete**.

5.4 DHCP Relay

The DHCP packet format is based on a BootP packet. As a result, DHCP uses the BootP relay agent to forward DHCP packets. This scheme provides interoperability between existing BootP clients and DHCP servers. The BootP relay agent uses the same criteria and methods for forwarding both DHCP and BootP packets. The DHCP Relay is disabled by default.

5.4.1 Enable the DHCP Relay

To enable the BOOTP/DHCP Relay complete the following steps:

STEP 1: Access the BOOTP/DHCP Relay screen by clicking on **DHCP** on the Advanced Menu, and then click the **DHCP Relay** tab.



The screenshot shows a web interface for DHCP Relay Configuration. At the top, there are two tabs: "DHCP Server" and "DHCP Relay". The "DHCP Relay" tab is active. Below the tabs, the title "DHCP Relay Configuration" is displayed. There are two input fields: "DHCP Relay" with a dropdown menu set to "Enable", and "IP Address" with an empty text box. At the bottom, there are two buttons: "Apply" and "Cancel".


STEP 2: In the DHCP Relay field, select **Enable**, and enter the IP Address you want to receive BOOT REQUEST or DHCP packets from clients.

STEP 3: Click on the **Apply** button.

5.4.2 Disable the BOOTP/DHCP Relay

To disable the BOOTP/DHCP Relay complete the following steps:

STEP 1: Access the BOOTP/DHCP Relay screen by clicking on **DHCP** on the Advanced Menu, and then click the **BOOTP/DHCP Relay** tab.




The screenshot shows a web interface for DHCP Relay Configuration. At the top, there are two tabs: 'DHCP Server' and 'DHCP Relay'. The 'DHCP Relay' tab is selected. Below the tabs, the title 'DHCP Relay Configuration' is displayed. The configuration area includes a 'DHCP Relay' dropdown menu with 'Disable' selected, an 'IP Address' text input field, and two buttons: 'Apply' and 'Cancel'.

STEP 2: In the DHCP Relay field, select **Disable**, and enter the IP Address you want to receive BOOT REQUEST or DHCP packets from clients.

STEP 3: Click on the Apply button.

5.5 SNMP

SNMP is a software entity that responds to information and action request messages sent by a network management station. The messages exchanged enable you to access and manage objects in an active or inactive (stored) MIB on a particular router. To configure the SNMP parameters, click the **SNMP** button on the **Advanced** menu bar. The window displays the SNMP parameters.




The screenshot shows a configuration window with a dark blue header bar containing three tabs: "System", "Traps", and "Communities". The "System" tab is selected. Below the tabs, the title "List of SNMP Parameters" is centered. A table displays the following parameters:

System Version Description	ADSL Termination Unit
System Contact	Phone:
System Location	
System ID	4242
IP Address of SNMP Agent	192.168.1.1
Port No. of SNMP Agent	161

Below the table are three buttons: "Modify", "Stop", and "Configure SNMP Agent".


5.5.1 Modifying SNMP Parameters

To modify the SNMP parameters, click the Modify button at the bottom of the screen. Click Apply to submit the settings.



The image shows a web-based configuration interface for SNMP. At the top, there are three tabs: "System", "Traps", and "Communities". The "System" tab is selected. Below the tabs, the title "SNMP Configuration" is centered. The form contains several input fields: "System Version" with the value "ADSL Termination Unit", "Description" with the value "Phone:", "System Contact" with the value "Phone:", "System Location" which is empty, and "System ID" with the value "4242". At the bottom of the form, there are two buttons: "Apply" and "Cancel".

To configure the SNMP agent, click the Configure SNMP Agent button. After filling out the fields, click Apply to submit the settings.



The image shows a web-based configuration interface for the SNMP agent. The title "Agent Configuration" is centered at the top. The form contains two input fields: "Interface Name" with a dropdown menu showing "eth0" and "Port" with the value "161". At the bottom of the form, there are two buttons: "Apply" and "Cancel".

5.5.2 Modifying Traps

Click the Traps tab to configure the traps. After filling out the parameters, click Submit to apply the settings.



The screenshot shows a web interface with three tabs: "System", "Traps", and "Communities". The "Traps" tab is selected. Below the tabs is a section titled "List of Trap Server Entries" containing a table with two rows of data. Each row has a radio button in the "Select" column. Below the table is a "Modify" button.

Select	Version	IP Address	Community	Status
<input type="radio"/>	1	0.0.0.0	public	Disable
<input type="radio"/>	2	0.0.0.0	public	Disable

Modify

5.5.3 Modifying Communities

Click the Communities tab to display the community entry. After filling out the parameters, click Submit to apply the settings.

Select	IP Address	Community	Access
No Community Entry Available			

There is no community set up by factory default. To add or modify an entry, click the Configure Community button. To delete an entry, tick the entry and click the Delete button. The following screen displays after clicking the **Configure Community** button. Enter the parameters and then click the **Apply** button.

Community Configuration


IP Address:

Community:

Access: ▼

5.6 Firewall

The ADSL router provides packet filtering and stateful packet inspection, it has denial of service protection against attacks such as ICMP Flood, Ping of Death, IP spoofing, Port Scans, Land Attack, Tear Drop Attack, IP Source Route and WinNuke Attack. To access the firewall functions, select **Firewall** from the advanced menu. The screen will display as below, showing a list of the currently configured filter entries. From the Firewall page, you can turn the Firewall Mode **On** or **Off**, view Filter Parameters, **add** a filter, **delete** a filter, or **View Action** for filtered packets. Each of these actions will be discussed below.



Select	Precedence	Interface	Src IP Addr/Netmask	Src Port	Protocol	FW Action
		Direction	Dest IP Addr/Netmask	Dest Port	Tcp Flags	FW Action ID
<input type="radio"/>	30000	eth0	172.16.11.0/24	=0	ANY	Allow
		In	0.0.0.0/32	=0	None	1
<input type="radio"/>	30000	usb0	192.168.201.0/24	=0	ANY	Allow
		In	0.0.0.0/32	=0	None	2
<input type="radio"/>	29000	Any	0.0.0.0/32	=0	UDP	Allow
		Any	0.0.0.0/32	=67	None	3
<input type="radio"/>	29000	Any	0.0.0.0/32	=520	UDP	Allow
		Any	0.0.0.0/32	=520	None	4

5.6.1 Enable/Disable the Firewall

To enable the firewall click on the **Enable/Disable** tab on the Firewall screen and then check the **Firewall Enable** box and click the **Apply** button. Conversely, to disable the firewall uncheck the **Firewall Enable** box and click the **Apply** button.



IP Filtering **Enable / Disable**

Firewall Mode

Firewall Enable


5.6.2 View Firewall Actions

Click **View Actions** to display the list of currently configured firewall actions. The parameters are as follows:

Action ID: Item number

Interface: The interface the filtering rule is created on.

Firewall Action: The action taken when packets are received that correspond to a filtering rule. **Allow** will permit packets to pass through the router, **Deny** will drop corresponding packets. **Reject** will reject packet with a response, e.g., sending a TCP reset. **Reset** rejects a packet with a reset flag.



Action Id	Interface	Direction	Firewall Action
1	eth0	In	Allow
2	Any	Any	Allow
3	Any	Any	Allow

OK

5.6.3 IP Filtering

On the Firewall menu, click Add to configure the IP filtering entries. Fill out the parameters below and click Apply to submit the settings. The parameters are as follows:

Policy Parameters:

Precedence: This number sets the priority level of the rule, smaller numbers have higher priorities, if a conflict between rules occurs, enter a number from 1-65534.

Src IP Address: Source IP address of the packet.

Src Net Mask: Source Netmask of the packet.

Dest IP address: Destination IP address of the packet.

Dest Net Mask: Destination Net mask of the packet.

Source Port: Source port of the packet (only for TCP/UDP protocol)

Destination Port: Destination port of the packet (only for TCP/UDP protocol)

Protocol: Select the protocol from the following: Any, TCP, UDP, ICMP, GRE, AH, ESP

TCP Flags: Select the TCP FLAG from the following: none, urg, ack, psh, rst, syn, fin.

Firewall Parameters

Existing Action ID: If an action has already been established, check the box next to **Existing Action ID** and enter its **Action ID**.

New Action: If a new action is required check the box next to **New Action** and then enter: **Interface Name** –the interface the action applies to, **FW Action:** Enter **Allow**, to enable packets to pass through the router, **Deny** to drop corresponding packets, **Reject** to reject packet with a response, e.g., sending a TCP reset, or **Reset** to reject a packet with a reset flag.

Direction – the direction can be **IN** – only packets received are affected. **OUT** –only packets sent are affected or **ANY** –both packets sent and received are affected.

Firewall Configuration

Policy Parameters

Precedence:

Src IP Address:

Src Net Mask: bits

Dest IP Address:

Dest Net Mask: bits

Source Port From: To:

Destination Port From: To:

Protocol:

TcpFlags:

For Standard Applications		
Application	Dest Port	Protocol
FTP	21	TCP
HTTP	80	TCP
TELNET	23	TCP
DNS	53	UDP
DHCP_CLIENT	68	UDP
DHCP_SERVER	67	UDP

Firewall Parameters

Existing

New Action

Interface Name:

FW Action:

Direction:

5.7 NAT

The NAT function can be accessed by clicking the **NAT** tab on the **Advanced** menu. From this screen you can add or delete a Static Wan Address, static NAT mapping or Port Range Mapping.

5.7.1 Static NAT Mapping

Any Static NAT mapping entries that are set up will be listed, click on the **Add** button add a new entry or select an entry and click on the **Delete** button.

List of Static Nat Mapping

Select	Local Address		Public Address
	From	To	
No NAT Outgoing entry			

Add an Entry

To add an entry click on the **Add** button, enter the Public IP Address you wish to set for NAT, enter the Local Address From (starting point for the range), enter the Local Address To (end point for the range), and then click on the **Apply** button.

Static NAT Configuration

NAT Public Address:

Local Address From:

Local Address To:

5.7.2 Static Port Mapping

Any Static WAN address that are set up will be listed, click on the **Add** button add a new entry or select an entry and click on the **Delete** button.

Select	Local Address	Local Port		Public Address	Public Port		Protocol
		From	To		From	To	
No NAT Incoming entry							

Add an Entry

To add an entry click on the **Add** button, and then enter the following information, and then click on the **Apply** button:

Public IP Address: Enter the you wish to set the Public port range

Public Port From: Enter the starting port for the Public port-range

Public Port To: Enter the last port for the Public port-range

Local Address: Enter the Local address

Local Port From: Enter the starting port for the Local port-range

Local Port to: Enter the last port for the Local port-range

Protocol: Select UDP or TCP

Port Range Configuration	
Public Address:	<input type="text"/>
Public Port From:	<input type="text"/>
Public Port To:	<input type="text"/>
Local Address:	<input type="text"/>
Local Port From :	<input type="text"/>
Local Port To:	<input type="text"/>
Protocol :	TCP <input type="button" value="v"/>

5.8 Configure

From this page, you can configure LAN and WAN interfaces, VCC, PPPoE, PPPoA, DNS & Default Gateway, and NAT.

Interfaces **VCC** **PPPoE** **PPPoA**

List of Interface Entries

Select	Interface Name	IP Address	Subnet Mask	MAC Address	Status
<input type="radio"/>	eth0	192.168.1.1	255.255.255.0	0:0:0:0:0:0	UP
<input type="radio"/>	mer0	None	None	NA	DOWN
<input type="radio"/>	wlan0	192.168.101.1	255.255.255.0	NA	UP
<input type="radio"/>	lo0	127.0.0.1	255.0.0.0	NA	UP
<input type="radio"/>	atm0	10.0.0.1	255.255.255.252	NA	UP
<input type="radio"/>	atm1	None	None	NA	DOWN
<input type="radio"/>	atm2	None	None	NA	DOWN
<input type="radio"/>	atm3	None	None	NA	DOWN
<input type="radio"/>	atm4	None	None	NA	DOWN
<input type="radio"/>	atm5	None	None	NA	DOWN
<input type="radio"/>	atm6	None	None	NA	DOWN
<input type="radio"/>	atm7	None	None	NA	DOWN
<input type="radio"/>	ppp0	None	None	NA	DOWN
<input type="radio"/>	ppp1	None	None	NA	DOWN
<input type="radio"/>	ppp2	None	None	NA	DOWN
<input type="radio"/>	ppp3	None	None	NA	DOWN
<input type="radio"/>	ppp4	None	None	NA	DOWN
<input type="radio"/>	ppp5	None	None	NA	DOWN
<input type="radio"/>	ppp6	None	None	NA	DOWN
<input type="radio"/>	ppp7	None	None	NA	DOWN

5.8.1 Configure Interface

To configure an interface, select it by clicking in the round-box on the left in the screen. Then click on the Configure Interface button at the bottom of the screen. Note the following:


Interfaces:

- ◆ **Interface mer0** usage is reserved; its status is always **Down**.
- ◆ **Interface lo0** is the loopback interface. When an OAM loopback is performed, the status field displays UP.
- ◆ **Interfaces Atm1 to Atm7** display the interfaces configured for RFC1483 Bridged mode or RFC 1483 Routed mode.
- ◆ **Interfaces pppo to ppp7** display the interfaces configured for PPPoE or PPPoA.

Parameters:

- ◆ **Dynamic IP address from DHCP:** Selects the IP address to be assigned by the DHCP server.
- ◆ **Static IP address:** Selects the IP address to be statically assigned.
- ◆ **Interface:** The name of the interface currently selected.
- ◆ **IP address:** The IP address of the selected interface.
- ◆ **Subnet Mask:** The subnet mask of the selected interface.
- ◆ **MTU:** Sets the maximum transmission unit of the interface. The MTU is used to limit the size of packets that are transmitted on an interface. Not all interfaces support the MTU parameter, and some interfaces, like Ethernet, have range restrictions (80 - 1500).
- ◆ **Status:** UP and Down. When an interface is set to **Down**, the system will not attempt to transmit messages through that interface. When set to **UP**, messages can be transmitted through the interface.

The following is a screen shot for the ATM interface.



The screenshot shows a configuration window titled "ATM Interface Configuration". At the top, there are four tabs: "Interfaces", "VCC", "PPPoE", and "PPPoA". The "Interfaces" tab is selected. The configuration fields are as follows:

Interface :	<input type="text" value="atm7"/>	IP Address :	<input type="text"/>
Subnet Mask :	<input type="text" value="255.255.255.0"/>	Status :	<input type="text" value="DOWN"/>
MTU :	<input type="text" value="1500"/>		


At the bottom of the dialog, there are two buttons: "Apply" and "Cancel".

5.8.2 DNS & Default Gateway

To configure the DNS and default gateway, complete the following steps:

STEP 1: Click on **Configure** in the menu bar.

STEP 2: Click on **DNS and default gateway** at the bottom of the configuration page.



The screenshot shows a configuration window titled "DNS & Default Gateway Configuration". It contains four input fields:

Domain Name :	<input type="text"/>
Primary DNS Server :	<input type="text"/>
Secondary DNS Server :	<input type="text"/>
Default Gateway :	<input type="text"/>

At the bottom of the dialog, there are two buttons: "Apply" and "Continue".

STEP 3: Complete the fields below:


- ◆ Domain Name: user-defined
- ◆ Primary DNS server: Enter the primary server IP address.
- ◆ Secondary DNS server: Enter the secondary server IP address that will be used in the event that the primary server IP address fails or is not available
- ◆ Default Gateway: The gateway IP address of the IP network

STEP 4: Submit the settings by clicking **Apply**.

5.8.3 NAT

The screen below is accessed by clicking the **NAT** button on the **Configuration** screen. To enable NAT check the Enable NAT box and the select the interface that you wish to enable NAT on.


1. Form the configuration menu click on the NAT button at the bottom-right side of the screen.
2. Check the **Enable NAT** box
3. Select the interface to enable NAT
4. Click the **APPLY** button
5. Click the **CONTINUE** button



The screenshot shows a dialog box titled "Nat Configuration" with a light blue background and a dark blue border. It contains two configuration options: "Enable Nat" with an unchecked checkbox, and "Interface Name" with a dropdown menu showing "ATMO". At the bottom, there are two buttons: "Apply" and "Continue".

5.9 VCC

This screen lists all current VCC entries in the middle of the screen. From this screen you can also: List IPoA, Delete Encapsulation, Add a VCC, Delete a VCC, and Show VCC quality.




The screenshot shows a web interface with a navigation bar at the top containing tabs for 'Interfaces', 'VCC', 'PPPoE', and 'PPPoA'. The 'VCC' tab is highlighted with a red box. Below the navigation bar, the title 'List of VCCs' is centered. A table displays three VCC entries. Below the table are several buttons: 'List Ipoa', 'Delete Encap', 'Add', 'Delete', and 'Show VCC Quality'.

Select	VPI	VCI	Type (Data/Voice)	Encapsulation	Interface	IPAddress
<input type="radio"/>	0	33	Data	Bridge	None	None
<input type="radio"/>	0	34	Data	Bridge	None	None
<input type="radio"/>	0	41	Data	None	None	None

5.9.1 List IPoA

To list IP over ATM information click on the **IPoA** button at the bottom-left of the screen.



The screenshot shows a dialog box titled 'List of IPOA'. It contains a table with columns: 'Interface Name', 'VPI', 'VCI', 'Encapsulation', 'Dest Address', 'State', and 'Type'. The table is currently empty, displaying the text 'IPoA not configured'. Below the table is a 'Close' button.

Interface Name	VPI	VCI	Encapsulation	Dest Address	State	Type
IPoA not configured						

The IPoA entry is set up from Advanced>Configure>VCC, Click the Add button on the List of VCC screen.

The screenshot displays the 'VCC Configuration' window with the following fields and values:

- VPI: []
- VCI: []
- Peak Cell Rate (cells/sec): 3000
- Avg. Cell Rate (cells/sec): 3000
- Burst Size (cells): 45
- CDVT (cells): 500000
- Type: Data
- Service Type: UBR

For data flow:

- Routed
- Interface: ATM0
- IPoA
- Interface: ATM0
- Default PVC:
- Next Hop IP Address: []

5.9.2 Delete Encapsulation

To delete encapsulation first select a VCC entry and then click the **Delete Encap** button.

5.9.3 Add a VCC

To add a VCC entry, complete the following steps:

STEP 1: Click on the Add VCC button, the VCC screen will appear.

STEP 2: Enter values for the parameters (explained below).

STEP 3: Click the **Apply** button at the bottom of the page.

vpi:	Virtual Path Identifier (VPI) that identifies this ATM connection. The vpi is integer numbers, which can range from 0 to 4095.
vci:	Virtual Channel Identifier (VCI) that identifies this ATM connection. The vci is an integer number which can range from 65,535.
Peak Cell rate (cells/sec):	Defines the fastest rate a user can send cells to the network. It is expressed in units of cells per second.
Average Cell rate (cells/sec):	Defines the maximum sustainable/average rate a user can send cells to the network. It is expressed in cells per second. This specifies the bandwidth utilization. This value must always be less than or equal to the Peak Cell Rate.
Burst size (cells):	Maximum number of cells the user can send at the peak rate in a burst, within a sustainable rate.
CDVT (cells):	Constrains the number of cells the user can send to the network at the maximum line rate.
Type:	Select data or voice
Service Type:	
cbr Constant Bit Rate:	Supports real-time applications requiring a fixed amount of bandwidth. The applications produce data at regular intervals such as a video stream. The user can specify how much bandwidth they wish to reserve.
rtvbr Real Time Variable Bit Rate:	Supports time-sensitive applications such as voice. In these applications the rate at which cells arrive are varied.
Nrtvbr Non Real Time Variable Bit Rate:	Supports applications that have no constraints on delay and delay variation, but still have variable-rate and bursty traffic characteristics.
Ubr Unspecified Bit Rate:	Best effort service that does not require tightly constrained delay and delay variation. UBR provides no specific quality of service or guaranteed throughput.

VCC Configuration

VPI :	<input type="text"/>	VCI :	<input type="text"/>
Peak Cell Rate (cells/sec):	<input type="text" value="3000"/>	Avg. Cell Rate (cells/sec):	<input type="text" value="3000"/>
Burst Size (cells):	<input type="text" value="45"/>	CDVT (cells):	<input type="text" value="500000"/>
Type :	<input type="text" value="Data"/>	Service Type :	<input type="text" value="UBR"/>

For data flow:

Routed
Interface :

IPoA
Interface :
Default PVC :
Next Hop IP Address :

PPPoA
Profile Id :
User Name :
Authentication Type :
Encapsulation Type :
SubnetMask :
Password :
Interface :
Trace :
NAT :

PPPoE
Profile Id :
User Name :
Authentication Type :
Mode :
Encapsulation Type :
SubnetMask :
Password :
Interface :
Idle Time (min) :
Trace :
NAT :

5.9.4 Delete a VCC


To delete a VCC entry, select the entry from the list of VCCs and then click on the **delete** button, at the bottom-right of the page.

5.9.5 Show VCC quality

To view information regarding the VCC quality, click on the **Show VCC Quality** button, at the bottom-right of the page.

5.9.6 PPPoE

This section will describe how to start, stop, delete, and set a default PPPoE entry. The PPPoE page can be accessed by clicking on **Configure** in the Advanced menu bar. To start, stop, delete, or set as default a PPPoE entry first select the entry from the List of PPPoE entries, and then click the corresponding button at the bottom of the page.



The screenshot displays the PPPoE configuration interface. At the top, a dark blue navigation bar contains four tabs: 'Interfaces', 'VCC', 'PPPoE', and 'PPPoA'. The 'PPPoE' tab is highlighted with a red rectangular border. Below the navigation bar, the page title 'List of PPPoE Entries' is centered. Underneath the title is a table with 14 columns: 'Select', 'Profile Id', 'Vpi', 'Vci', 'Interface Name', 'UserName', 'Password', 'Authentication Protocol', 'Mode', 'Idle TimeOut', 'Nat', 'Subnet Mask', 'Valid', 'Active', and 'Default'. The table body contains the text 'No PPPoE Entry Available'. At the bottom of the page, there are four buttons: 'Start', 'Stop', 'Delete', and 'Default'.

5.10 PPPoA

This section will describe how to start, stop, delete, and set a default PPPoA entry. The PPPoA page can be accessed by clicking on **Configure** in the Advanced menu bar. To start, stop, delete, or set as default a PPPoA entry first select the entry from the List of PPPoA entries, and then click the corresponding button at the bottom of the page.

The screenshot shows the 'List of PPPoA Entries' page. At the top, there are four menu items: 'Interfaces', 'VCC', 'PPPoE', and 'PPPoA'. The 'PPPoA' menu item is highlighted with a red box. Below the menu items, the title 'List of PPPoA Entries' is displayed. Underneath the title is a table with the following columns: Select, Profile Id, Vpi, Vci, Interface Name, UserName, Password, Authentication Protocol, Nat, Subnet Mask, Valid, Active, and Default. The table is currently empty, displaying the text 'No PPPoA Entry Available'. Below the table, there are four buttons: Start, Stop, Delete, and Default.

5.11 IGMP

IGMP (Internet Group Membership Protocol) is a protocol used by IP hosts to report their multicast group memberships to any immediately neighboring multicast routers.

The screenshot shows the 'List of IGMP Proxy Entries' page. At the top left, there is a tab labeled 'IGMP Proxy'. Below the tab, the title 'List of IGMP Proxy Entries' is displayed. Underneath the title is a table with the following columns: Select, InterfaceName, Type, and Ip Address. The table is currently empty, displaying the text 'No IGMP Interfaces configured'. Below the table, there are two buttons: Add and Delete.

5.11.1 Add an IGMP entry


To add an IGMP proxy, complete the following steps:

STEP 1: Select **IGMP Proxy**, from the menu bar.

STEP 2: Click **Add** at the bottom of the screen.

STEP 3: Select Proxy interface, router interface, or both, by checking the box next to the interface and then use the pull-down menu to the left to select the eth, atm, or ppp Interface.

STEP 4: Click **Apply** to activate the parameters.



The screenshot shows a configuration window titled "IGMP Proxy" with a sub-header "IGMP Proxy Configuration". It contains two rows of configuration options, each with a checkbox and a dropdown menu. The first row is "Proxy Interface : eth0" and the second row is "Router Interface : eth0". At the bottom of the window are two buttons: "Apply" and "Cancel".


5.11.2 Delete an IGMP entry

To delete an entry, select an entry from the list, and click **Delete**.

5.12 Bridging

5.12.1 Bridge

The Bridge window displays the configured Bridging PVC entries of the interfaces. There are four buttons at the bottom of the main-pane: Group Info, Add PVC, Flush, and Disable.




The screenshot shows a window titled "Bridge" with tabs for "Bridge", "Spaning Tree", and "Filters". The main area is titled "List of Bridge Entries" and contains a table with the following data:

Interface Name	State	MAC Address	Priority	Link Cost	Vpi	Vci	Encapsulation	VPN OUI	VPN ID
eth0	FORWARDING	00:00:00:00:00:00	128	100	NA	NA	NA	NA	NA
atm7	FORWARDING	NA	128	250	0	33	LLC	0	0
atm7	FORWARDING	NA	128	250	0	34	LLC	0	0

Below the table are four buttons: "GroupInfo", "AddPVC", "Flush", and "Disable".

- ◆ **GroupInfo:** This configures the LAN packets that will travel through the LAN interface to the selected WAN interfaces. If you wish to change the interfaces that are configured you must first click on the **Flush button** (to remove the current configuration), and then click on the **Group Info** button, select the group interfaces and then click the **Apply** button. You must select eth0, as eth1 is not enabled for this product version.



The screenshot shows a dialog box titled "Group Interfaces" with a list of checkboxes for selecting interfaces:

- Eth0
- Wlan0
- Atm0
- Atm1
- Atm2
- Atm3
- Atm4
- Atm5
- Atm6
- Atm7

At the bottom of the dialog are two buttons: "Apply" and "Cancel".

- ◆ **AddPVC:** You can add a PVC to the ATM interface. From the **Bridging** screen, select an ATM interface Vpi, Vci and Encapsulation type and then click **Apply**.

Bridge Configuration

Interface Name :

Vpi :

Vci :

Encapsulation Type :

- ◆ **Flush:** Selecting this command from the **Bridging** screen, will flush all PVC entries.
- ◆ **Disable:** Selecting this command from the **Bridging** screen, will disable the PVCs but retain the parameters, so that they can be enabled at a later point.

5.12.2 Spanning tree

To access the spanning tree menu click the **Spanning Tree** tab, located at the top of the **Bridging** screen.

List of Spaning Tree Entries

Select	Port	State	Port Id	Link Cost	Tx CBpdu	Rx CBpdu	TX TBpdu	RX TBpdu
<input type="radio"/>	1	Forwarding	32769	100	0	0	0	0
<input type="radio"/>	2	Forwarding	32770	250	0	0	0	0

5.12.3 View STP Parameters

To view the STP parameters, click the **STP parameters** tab, located at the bottom of the Spanning Tree screen.

List of Spaning Tree Parameters

STP	Disabled
Active Ports	2
Bridge Id	00:00:00:00:80:00
Root Id	00:00:00:00:00:00
Hello Time	2
Max Age	20
Forwarded Delay	15
Root Port	0
Root Path Lost	0
Hold Time	1

[Continue](#)


5.12.4 To configure STP parameters

STEP 1: click the **Spanning Tree** tab, located at the top of the **Bridging** screen.

STEP 2: Click the Configure Port button.

STEP 3: Configure the parameters.

STEP 4: Click the Apply button.



The screenshot shows a 'Port Configuration' dialog box with three tabs: 'Bridge', 'Spaning Tree', and 'Filters'. The 'Spaning Tree' tab is selected. The dialog is divided into two sections: 'Port Parameters' and 'Bridge Parameters'. In the 'Port Parameters' section, the 'Interface Name' is set to 'Eth0' (shown in a dropdown menu), and the 'Link Cost' is an empty text box. The 'Port Priority' is also an empty text box. In the 'Bridge Parameters' section, there are four checkboxes, all of which are unchecked. The 'Bridge Priority' is set to '32768', 'Max Age Time' is '20', 'Hello Time' is '2', and 'Forward Delay Priority' is '15'. At the bottom of the dialog are 'Apply' and 'Cancel' buttons.

5.12.5 Enable/Disable STP

If you wish to Enable/Disable a STP entry, select the entry and then click the **Enable** or **Disable** Button, which is located at the bottom-right of the Spanning Tree screen. Note that if the entry is already enabled the Disable button will be present. Conversely, if the entry is disabled then the Enable button will be present.

5.13 Filtering

Filtering is a type of firewall that is useful to increase network security or to limit unwanted traffic. Filters for this device are based on MAC addresses. The page opens with a list of the currently configured filter entries. From this page, you can also view Filter Parameters, add a filter, delete a filter, modify a filter, or flush filter parameters. These functions are described below.

Select	Name	Port	MAC Address	Age	Action
<input type="radio"/>	None	0	ff:ff:ff:ff:ff:ff	Static	Forward
<input type="radio"/>	None	0	00:00:00:00:00:00	Static	Forward
<input type="radio"/>	eth0	1	00:d0:59:0e:05:0c	Dynamic	Forward
<input type="radio"/>	eth0	1	00:48:54:5e:ed:a1	Dynamic	Forward

Filter Parameters Add Delete Modify Flush

5.13.1 List of filter entries

To display a list of filter parameters click the **Filter parameters** button at the bottom of the Filters page. The following parameters are displayed:

Maximum filter entries	The number of filter entries that can potentially be set
Total filter entries	The number of filter entries that are currently set
Total static entries	The number of static entries that are currently set
Total dynamic entries	The number of dynamic entries that are currently set

Maximum Filter Entries	1024
Total Filter Entries	22
Total Static Entries	3
Total Dynamic Entries	19

Continue

5.13.2 Add a filter entry


To add a filtering entry, complete the following steps:

STEP 1: Click the **Add** button at the bottom of the Filters page.

STEP 2: Enter the MAC address

STEP 3: Set the Frame to **forward** to forward packets which match the MAC address, or **Drop**, to drop matching packets.

STEP 4: Click **Apply**.



The screenshot shows a web-based configuration interface with three tabs: Bridge, Spaning Tree, and Filters. The Filters tab is active. The main heading is "Filter Configuration". Below the heading, there is a "MAC Address" label followed by an empty text input field. Below that is a "Frame" label followed by a dropdown menu currently set to "Forward". At the bottom of the configuration area, there are two buttons: "Apply" and "Cancel".

5.13.3 Delete a filter entry

To delete a filtering entry Select an entry and then click the **Delete** button at the bottom of the Filters page.

5.13.4 Modify a filter entry

To modify a filter select the entry and then click the **Modify** button at the bottom of the Filters page.


5.13.5 Flush filter entries

To flush all the filtering entries, click the **Flush** button at the bottom of the Filters page.

Chapter 6 Web Performance monitoring

6.1 ADSL Link Status

To view the ADSL link status, click **Link Status** on the tool bar.



The screenshot shows a window titled "LinkStatus" with a sub-header "ADSL Link Status". Below the header is a table with the following data:

Adsl Line Status	UNTRAINED
Adsl Mode	MULTI
Up Stream	0 kb (Interleave)
Down Stream	0 kb (Interleave)
Attenuation	Near End: 0.0
	Far End: 0.0
SNR Margin	Near End: 0
	Far End: 0
HEC Count	0
Firmware	0x42e2ea53
15 min ES Counter	0
CRC Errors	0
1 day ES Counter	0

ADSL Line Status	Shows the current status of the ADSL line
ADSL Mode	Shows the ADSL standard that is currently configured. The standards are: ANSI, G.DMT, G.LITE, MULTI.
Upstream	Upstream data rate negotiated by DSL link (Kbit/s)
Downstream	Downstream data rate negotiated by DSL link (Kbit/s)
Attenuation	Current attenuation (dB).
SNR Margin	Current SNR margin (dB)
HEC	Number of ATM cells received with errors since start of link.
Firmware	The version number of the firmware
15 min ES counter	Number of errored seconds for the current 15 minute period
CRC errors	Number of errors per second since training
1 day ES counter	Number of errored seconds for the current day

6.2 System Statistics

To view the system statistics, click on the **System Statistics** button located near the bottom of the menu-bar. Statistics are recorded regarding Interfaces, TCP-IP, and DHCP-Lease.

6.2.1 Interface Statistics

To display the interface statistics, click the **Interface** tab, located at the top-left of the System Statistics screen. The Interface Statistics page displays statistics for all interfaces. The following information is displayed:

Interface Name	The name of the interface
Admin Status	Indicates whether the interface is Up or Down
Octets In	The number of Octets (bytes) recieved
Unicast PktsIn	The number of unicast packets received
Broadcast PktsIn	The number of broadcast packets received
Discards In	The number of packets received that were discarded
Errors In	The number of inward errors
Octets Out	The number of Octets (bytes) transmitted
Unicast PktsOut	The number of unicast packets transmitted
Broadcast PktsOut	The number of broadcast packets transmitted
Discards Out	The number of packets transmitted that were discarded
Errors Out	The number of outward errors

Interface Statistics											
Interface Name	Admin Status	Octets In	Unicast PktsIn	Broadcast PktsIn	Discards In	Errors In	Octets Out	Unicast PktsOut	Broadcast PktsOut	Discards Out	Errors Out
eth0	UP	215927	1721	0	0	0	253206	355	0	0	0
mer0	UP	0	0	0	0	0	0	0	0	0	0
wlan0	UP	0	0	0	0	0	0	0	0	0	0
lo0	DOWN	0	0	0	0	0	0	0	0	0	0
atm0	UP	0	0	0	0	0	0	0	0	0	0
atm1	DOWN	0	0	0	0	0	0	0	0	0	0
atm2	DOWN	0	0	0	0	0	0	0	0	0	0
atm3	DOWN	0	0	0	0	0	0	0	0	0	0
atm4	DOWN	0	0	0	0	0	0	0	0	0	0
atm5	DOWN	0	0	0	0	0	0	0	0	0	0
atm6	DOWN	0	0	0	0	0	0	0	0	0	0
atm7	DOWN	0	0	0	0	0	0	0	0	0	0
ppp0	DOWN	0	0	0	0	0	0	0	0	0	0
ppp1	DOWN	0	0	0	0	0	0	0	0	0	0

6.2.2 TCP-IP

To view TCP-IP statistics click on the **TCP-IP** tab at the top of the System Statistics page. The TCP-IP page displays the IP statistics, UDP statistics, TCP statistics, and ICMP statistics.

TCP-IP Statistics							
IP Statistics							
In receives	718	In Errors	0	In Unknown Protos	17	Forwarded Datagrams	374
Out Requests	374	Out Discards	0	Out No Routes	0		
Udp Statistics							
Data grams In	297	Datagrams Out	0	Errors In	0		
Tcp Statistics							
Active Opens	0	Passive Opens	27	Attempt Fails	0	Current Establishments	1
Segments In	405	Segments Out	376	Segments retransmitted	0	Errors In	0
Icmp Statistics							
IN							
Messages	17	Errors	0	Destination	0	Time	0

6.2.3 DHCP-Lease

To view TCP-IP statistics click on the **DHCP-Lease** tab at the top of the System Statistics page. The DHCP-Lease page shows the PCs that obtained an IP address from the DHCP pool.


DHCP-Lease Statistics				
Lease-IP	Start time	End time	Stamp	H/W Address
Dhcp Server not Started				

6.3 ATM statistics

Click on **ATM Statistics** on the menu-bar to display the ATM Statistics. The ATM Statistics page monitors information for AAL5 and Encapsulation.

6.3.1 AAL5


The AAL5 page shows the AAL5 statistics.



AAL5 Statistics	
Transmitted Cells	0
Received Cells	0
CRC Errors	0

6.3.2 Encapsulation

Click on the **SNDP** tab to display encapsulation statistics. This page displays the VCs that are running. (SNDP stands for sub-network dependency convergence protocol).



VPI	VCI	Encapsulation Method	Packets In	Packets Out	Packets Dropped	Packets Bridged
No SNDP Statistics Available						

7.2 Ping

A Ping test is used to verify the status of a network connection after the RIP or static route function is enabled. Ping sends a request message to the host and waits for a return message. This diagnostic function can verify if the remote host is reachable. Ping can also measure the round-trip time to the remote host.

To access the Ping test screen, click the **Ping** tab on the Diagnostics screen.

Enter the **Host Name** or **IP address** of the remote terminal and click **Submit** to start the ping and display the results.



The following is an example of the ping result. The information displayed is as follows:

Packets transmitted	The number of packets that were transmitted
Packets received	The number of packets that were received
Packets lost	The number of packets lost (transmitted-received)
Minimum round trip time	The fastest round-trip time
Maximum round trip time	The slowest round-trip time



Ping Statistics	
Packets Transmitted	4
Packets Received	4
Packet Loss (%)	0
Minimum Round Trip Time	0.000
Maximum Round Trip Time	0.000

Chapter 8 Firmware Upgrade

Follow the steps below to upgrade the firmware version of the wireless router via the FTP:

STEP 1: Connect the Router to a PC using the LAN cable. Set the PC to the same subnet as the router (192.168.1.1).

STEP 2: Restore the default parameters to the wireless router by holding down the device's **Reset** button until the **Power** LED turns red (about 5 seconds). [Or you can reboot the wireless route by running the device software and going to the **Erase and Reboot** menu and selecting the **ERASE** command.].

STEP 3: Start DOS and enter the menu where the new firmware is installed:

Example: C:\Upgrade

STEP 4: Enter the command: ftp 192.168.1.1 (router's IP address)

```
C:\>ftp 192.168.1.1
```

STEP 5: At the USER prompt type **root** (small case)

```
Connected to 192.168.1.1.  
220 welcome to the update FTP server v1.0.  
User (192.168.1.1:(none)): root
```

STEP 6: At the Password prompt type **12345**

```
331 Password required for root.  
Password:
```

STEP 7: After you see the message **User logged in**, type: **bin**

```
230 User logged in.  
ftp> bin
```



Chapter 9 Access by Telnet

This chapter will introduce the command line interface using Telnet. The chapter is divided into two parts. The first part explains how to set the PC and router to the same network segment, the second part explains how to start a Telnet session.

9.1 Setting a Common IP Address

To log on to the device using Telnet, your workstation and the router should both be on the same network segment. You can **modify the IP address of your PC** by modifying its TCP/IP. Follow the steps below:

STEP 1: Enter the TCP/IP screen and change the IP address to the domain of 192.168.1.x/24. You should choose an IP address from 192.168.1.132-192.168.1.254 to avoid conflict with IP addresses reserved for the DHCP pool (192.168.1.3 to 192.168.1.131).



STEP 2: Click OK to submit the settings.

STEP 3: Start Telnet with the default IP address 192.168.1.1.

9.2 Telnet Access

To access Telnet to manage your router complete the following steps:

The default IP address is 192.168.1.1. Use the default IP address to log on to the router if it was not changed.

- STEP 1** Make sure that the router and your Telnet-PC are on the same network segment.

- STEP 2** Connect the LAN port of the router to Ethernet or PC with an RJ45 cable.

- STEP 3** Click Windows Start menu and type Telnet x.x.x.x
(x.x.x.x represents the IP address)

- STEP 4** You will be prompted to enter a User name and Password, enter **root** for User name and **12345** for the Password.


- STEP 5** The first screen of the CLI interface will now display.

Chapter 10 Console Management

This section of the manual deals with console management of the router.

10.1 Hardware connection

In order to manage your device through the console port you will need to use a straight-through cable with an **RJ-45 connector** to attach to the modem, and a **female RS-232 connector** to connect to the serial port on a PC. The PC must be equipped with a VT-100 emulation program, such as HyperTerminal 5 or Telix.



10.2 Access by Console

For access by console, the console PC should be installed with a standard VT-100 emulation program, such as HyperTerminal 5 or Telix. The following steps describe how to establish the console session.

- Step 1 Start a standard VT-100 program such as HyperTerminal (Ver. 5 is recommended), or Telix in the local terminal; and select an open com port.
- Step 2 Enter the following port settings:
- Baud rate: 9600
 - Data bits: 8
 - Parity: none
 - Stop bit: 1
 - Flow control: none

10.3 Console WLAN Guide

Parameters that specifically deal with the wireless functions of your router can be accessed from the **WLAN Parameters** menu, located at **BASIC/WLAN CONFIGURATION**. The menu is subdivided into three menus: Basic Settings, Advanced Functions and WEP Functions. Each of these menus will be covered below.

```
*****  
*                               *  
*          Configure Wireless LAN Interface          *  
*-----*  
* 1. Basic Parameters *  
* 2. Advance Parameters *  
* 3. WEP Parameters *  
* 4. WLAN Access Control *  
* *  
* *  
* Esc. Previous Menu *  
* 0 . Main Menu *  
* Enter Your Choice:___ *  
* *  
* ***** Enter Your Choice ***** *  
*****
```

10.3.1 WLAN Basic Parameters

To configure WLAN basic Parameters go to **BASIC/WLAN CONFIGURATION/BASIC PARAMETERS**, enter values for the required parameters and then press the **Y** key when prompted by the following message **Do You Wish To Submit These Values [Y/N]**. The WLAN Basic Parameters menu includes the parameters listed below:

IP Address	Enter the IP address for the WLAN interface
Subnet Mask	Enter a subnet mask for the WLAN interface
MAC Address	Enter a MAC address to limit access to the router (only packets destined for this MAC address will be accepted by the router).
SSID	The SSID should match with your client adapters. The SSID (Service Set ID) allows you to uniquely identify your Access Point in the radio environment.
Channel	The channel should match with client adapters. The Direct Sequence Spread Spectrum (DSSS) channel number is an identifier for the frequency on which your WLAN connectivity is enabled in the WLAN network. Although the configurable DSSS channel number range is from 1 up to 13, restrictions apply depending on the country where the Wireless ADSL-Router is used: FCC : channels 1 to 11 ETSI : channels 1 to 13.

10.3.2 WLAN Advanced Functions

To configure WLAN Advance Parameters go to **BASIC/WLAN CONFIGURATIION/ADVANCE PARAMETERS**, enter values for the required parameters and then press the **Y** key when prompted by the following message **Do You Wish To Submit These Values [Y/N]**. The WLAN Advanced Functions menu includes the parameters listed below:

Beacon Interval	Default =100. Specify the Beacon Interval value. Enter a value between 1 and 1000. The value represents the time in nano-seconds that Beacon packets are sent by an Access Point to synchronize a wireless network.
RTS Threshold	This value should normally remain at its default setting of 2,432. Should you encounter inconsistent data flow, only minor modifications are recommended. The value must match with remote clients. The value must be between 0-3000.
Fragmentation	This field is used to specify the fragmentation threshold. Enter a value between 256 and 2346. If you experience a high packet error rate, try to slightly increase your Fragmentation Threshold. The value should normally remain at its default setting of 2,346. This value must match client adapters. The value must be between 256 – 2346 and must be an even number.
DTIM Interval	Enter a value between 1 and 65535, This number represents the time between sending delivery traffic identification messages (DTIMs) used for power saving and multicast/broadcast delivery. A DTIM is a countdown informing clients of the next window for listening to broadcast and multicast messages. When the AP has buffered broadcast or multicast messages for associated clients, it sends the next DTIM with a DTIM Interval value. AP Clients hear the beacons and awaken to receive the broadcast and multicast messages.
Tx Rates	The transfer rate of the router should be equal to or greater than the clients, the options are: 1(1M), 3(2M), 7(5M), 15(11M), 31(22M)
Preamble Type	Select 0 (Long Preamble) or 1 (Short Preamble) Should match client adapters. Short enables faster throughput, but it can only be used when all network elements comply with the IEEE 802.11b standard.
Auth. Type	Select 1 (Open System) or 2 (Shared Key) . Open System [no security], Shared Key [select this option if you wish to enable WEP security], if you select both , then both Open System and Shared Key will be simultaneously enabled.
Antenna Selection	Select 1 (Left spread on), 2 (Right spread on), 3 (Diversity spread on). Diversity enables both antennas, or you can select left or right to only enable one antenna.

Appendix A: Specifications

Wireless Card

Standard	IEEE802.11b
Encryption	64, 128-bit Wired Equivalent Privacy (WEP) Data Encryption
Channels	11 Channels (US, Canada) 13 Channels (Europe) 14 Channels (Japan)
Data Rate	11Mbps / 5.5Mbps / 2Mbps / 1Mbps Auto-Fallback
RF Frequency	2412 MHz – 2484 MHz (Japan) 2412 MHz – 2462 MHz (North America) 2412 MHz – 2472 MHz (Europe) 2457 MHz – 2462 MHz (Spain) 2457 MHz – 2472 MHz (France)

Wireless Antenna Twin external Dipole Antenna

LAN Interface (Four port Ethernet switch)

Standard	IEEE802.3 10/100Base-T
----------	------------------------

WAN Interface (One ADSL port)

ADSL standard	ANSI T1.413 Issue 2, G.DMT, G.lite
G.DMT data rate	Downstream: 11 Mbps Upstream: 1 Mbps
G.lite data rate	Downstream: 1.5 Mbps Upstream: 512 Kbps

ATM Attributes

PPP over AAL5	RFC 2364
Multi-protocol over AAL5	RFC 2684 (RFC 1483) Bridge RFC 2684 (RFC 1483) Route
PPP over Ethernet	RFC 2516
VCs	8
AAL type	AAL5
ATM service class	UBR/CBR/VBR
ATM UNI support	UNI3.1
OAM F4/F5	Yes

Management

LED Indicators	Power, LAN status, LAN ACT, ADSL status, Wireless LAN status, Wireless LAN ACT
Web-based management	Yes
Telnet	Yes
SNMP	Yes
Console port	RS232/DB9

Bridge Functions

Transparent bridging and learning	IEEE 802.1d
VLAN IEEE 802.1q transparent	Yes
Spanning Tree Algorithm	Yes

Routing Functions

Routing	Static route, RIP, and RIPv2
NAT/PAT	Yes

Security

Authentication protocols	PAP, CHAP, MS-CHAP
VPN features	PPTP/L2TP pass through

Power Supply

100, or 220 VAC

Dimensions

205 * 145 * 48 mm

Specifications are subject to change without notice

Appendix B - Pin Assignments

Pin Definitions of the LAN port

Pin number	Definition	Pin number	Definition
1	Transmit data+	5	NC
2	Transmit data-	6	Receive data-
3	Receive data+	7	NC
4	NC	8	NC


Note: NC means No connection

Pin Assignments of RJ11 Port

Pin	Definition	Pin	Definition
1	-	4	TIP
2	-	5	-
3	RING	6	-

Note: NC means No connection

Console cable



DB9 End Pins	COLOR	RJ-45 End Pins
N/C	WHITE/ORANGE	P1
N/C	ORANGE	P2
P3 (RD)	WHITE/GREEN	P3
P2 (TD)	BLUE	P4
N/C	WHITE/BLUE	P5
N/C	GREEN	P6
P5 (GRD)	WHITE/BROWN	P7
N/C	BROWN	P8